



*Proven Performance
for Over 50 Years*

1061/62 Manual

MODELS 1061/1062

PRECISION RATEMETER/TOTALIZER

INSTALLATION AND PROGRAMMING MANUAL



15555 North 79th Place
Scottsdale, AZ 85260
tel: (480) 922-7446 • fax: (480) 948-3610
Email: sales@cox-instruments.com
Web: www.cox-instruments.com

Table of Contents

<u>Title</u>	<u>Page</u>
Specifications.....	1
Dimensional Specifications.....	2
Programming Instructions.....	3-6

MODELS 1061 & 1062 SPECIFICATIONS

POWER

Internal Battery : 3V, Lithium
Life expectancy: 5 years +

PHYSICAL

Operating Temp.: -20°C to 70°C
Storage Temp.: -40°C to 70°C
Operating Humidity:
 90% Non-condensing
Weight: 2.2 oz. net
Display Size: 0.43" high
Front Panel Rating: Nema 4X when
mounted with gasket provided
Case Material: Cycolac X-17

TOTALIZER

Type: UP counting
Digits: 8.
Scaler: 0.0001 – 100.0000
 (0.0000 scales by 100 in the
 Courier Series)
Decimal Point: 5 positions,
programmable

RATE INDICATOR

Type: 1/Tau
Digits: 4/5, (4 calculated, 5
displayed with fixed 0 in LSD)
Scaler Range: .001 to 9999
Decimal Point: 5 positions,
programmable
Accuracy: ± 0.20 %
Update Time: 0.7 seconds
Zero Time: 10 seconds

DC COMMON (Terminal 1)

COUNT/RATE INPUTS

INPUT A

(TERMINAL 2 AND TERMINAL 3)

MAGNETIC PICKUP/ PULSE

Speed: Varies depending on unit
Voltage Range: Varies depending
on unit

RESET INPUT (TERMINAL 4)

Resets totalizer to zero when
connected to DC common
Min. Low Time: 0.25 to 1.0 sec.
(maintained)
The required pulse width varies with
count speed, scale factor and
number of digits displayed
Voltage Thresholds:
 Low: 0 to 0.4 VDC
 High: 2.0 to 28 VDC


**PROGRAM ENABLE INPUT
(Terminal 5)**

Operation: Level sensitive
(maintained)

COUNT ACCURACY

100% when operated within
specifications

DIMENSIONS



1061/62 Installation and Maintenance Manual

Programming Mode

To enter the programming mode, a jumper connection must be made between terminals 1 and 5.

Programming Screens

There are six programming functions.

Programing Screens	
Screen	Function
1	Totalizer Scaling Factor
2	Totalizer Decimal Point Factor
3	Rate Scaling Factor
4	Rate Decimal Point Display
5	Rate Scaling Multiplier

1. Totalizer Scaling Factor

The totalizer scale factor, *TSF* is used to convert the incoming pulses to the desired units of measurement to be displayed. (i.e. lbs., gallons, etc.)

Scale factor range: 0.0001 to 99.9999

The following formula is used to calculate the proper scale factor setting:

$$TSF = \frac{DPF}{K - factor}$$

Where *DPF* is the Decimal point factor. See program section 2., and the *K-factor* is retrieved from the calibration data sheet for the flow turbine.

- When the far right digit is flashing, press the RTS[▲] key until the desired value is reached.
- Next, momentarily pressing the T/R[◀] key will move the flashing digit one place to the left.
- Repeat the above steps to set for the desired value at that place and repeat for all digits requiring changes.
- Pressing and holding the T/R[◀] key and momentarily pressing the RTS[▲] key will move to the next programming screen.

Note: Pressing and holding either of the keys during these functions will cause them to autscroll.

2. Totalizer Decimal Point Factor

The *DPF* is the decimal point factor number corresponding to the desired decimal point location used in the display of the totalizer. These are set using the following table.

Unit Display		<i>DPF</i> number
XXXXXX	=	1
XXXXX.X	=	10
XXXX.XX	=	100
XXX.XXX	=	1,000
XX.XXXX	=	10,000

EXAMPLE: A flow sensor produces 5520 pulses per gallon (*K-factor*), and has an equivalent flow rate of 9.77 GPM. Choosing a *DPF* to be XXXX.XX the following calculation would be done:

$$TSF = \frac{100}{5520} = 0.0181 \text{ (gal per 100 counts)}$$

- Press the RTS[▲] key to move the decimal point to the desired position.
- Pressing and holding the T/R[◄] key and momentarily pressing the RTS[▲] key will move to the next programming screen.

3. Rate Scaling Factor

The third program mode screen allows you to enter the rate scale factor, *RS*.

Calculating the Rate Scale Factor

The ratemeter calculates rate by measuring the time interval between input pulses (T_0), and converting that period to a frequency ($1/T_0 = \text{freq.}$), then multiplying the frequency by the rate scale factor to produce a calculated flow rate. The rate scale factor (*RS*) is user programmed to convert the count input frequency into the desired rate units for display. (i.e. feet/minute, Lbs/hour, gallons/minute)

Rate Scale Factor (*RS*): 0.001 to 9999

1061/62 Installation and Maintenance Manual

The following formula is used to calculate the proper rate scale factor (*RS*):

- When the far right digit is flashing. Press the RTS[▲] key until the desired value is reached.
- Next momentarily pressing the T/R[◀] key will move the flashing digit one place to the left.
- Repeat the above steps to set for the desired value at that place and repeat for all digits requiring changes.
- When the “d” appears, press the RTS[▲] key until the decimal point is in the desired location.

Note: This decimal point is used for the rate scale factor only and will not appear on the screen. The decimal point on the screen is programmed using program location number 4 in conjunction with the DPF number.

- Pressing and holding the T/R[◀] key and momentarily pressing the RTS[▲] key will move to the next programming screen.

4. Rate Decimal Pt. Display

Unit Display	=	DPF number
XXXX	=	1
XXX.X	=	10
XX.XX	=	100
X.XXX	=	1,000

$$RSF = \frac{SEC * DPF}{K - factor * RM}$$

where: *SEC* is the number of seconds in the rate time unit
(i.e. gal/sec = 1, gal/minute = 60, gal/hr = 3600)

DPF is the decimal pt. factor, similar to above in the *TSF*
but with new scale factor numbers. Note above chart.

- Press the RTS[▲] key until the desired DPF display is reached. Pressing and holding the T/R[◀] key and momentarily pressing the RTS[▲] key will move to the next programming screen.

5. Rate Scaling Multiplier

RM is the rate scale multiplier which has a programmable value of 1 or 10. This gives the programmer the ability to scale the *RSF* for better resolution to the *RSF* number.

- Press the key to choose the multiplier you want.

6. Reset Enable / Disable

The last screen in the program mode is used to determine whether the front panel reset key will function. The screen will show a number 6 on the left, for the screen number, and a R on the right, meaning that the unit's key is enabled and will reset the totalizer.

- Pressing the key will choose the desired setting.

When the display shows 'no R' the is disabled.

Exit Program Mode

To exit the program mode, remove the jumper connection between terminals 1 and 5.

1061/1062 Reference Manual
Part # 99S0006R0010, Rev. 1.1
5/07 Printed in USA
090804

